

- (h) Corrosion inhibitor treatment;
- (i) Removing or replacing subsurface pumps;
- (j) Through-tubing logging (diagnostics);
- (k) Wireline fishing; and
- (l) Setting and retrieving other subsurface flow-control devices.

Workover operations mean the work conducted on wells after the initial completion for the purpose of maintaining or restoring the productivity of a well.

§ 250.602 Equipment movement.

The movement of well-workover rigs and related equipment on and off a platform or from well to well on the same platform, including rigging up and rigging down, shall be conducted in a safe manner. All wells in the same well-bay which are capable of producing hydrocarbons shall be shut in below the surface with a pump-through-type tubing plug and at the surface with a closed master valve prior to moving well-workover rigs and related equipment unless otherwise approved by the District Supervisor. A closed surface-controlled subsurface safety valve of the pump-through-type may be used in lieu of the pump-through-type tubing plug provided that the surface control has been locked out of operation. The well to which a well-workover rig or related equipment is to be moved shall also be equipped with a back-pressure valve prior to removing the tree and installing and testing the blowout-preventer (BOP) system. The well from which a well-workover rig or related equipment is to be moved shall also be equipped with a back pressure valve prior to removing the BOP system and installing the tree. Coiled tubing units, snubbing units, or wireline units may be moved onto a platform without shutting in wells.

§ 250.603 Emergency shutdown system.

When well-workover operations are conducted on a well with the tree removed, an emergency shutdown system (ESD) manually controlled station shall be installed near the driller's console or well-servicing unit operator's work station, except when there is no

other hydrocarbon-producing well or other hydrocarbon flow on the platform.

§ 250.604 Hydrogen sulfide.

When a well-workover operation is conducted in zones known to contain hydrogen sulfide (H₂S) or in zones where the presence of H₂S is unknown (as defined in § 250.490 of this part), the lessee shall take appropriate precautions to protect life and property on the platform or rig, including but not limited to operations such as blowing the well down, dismantling wellhead equipment and flow lines, circulating the well, swabbing, and pulling tubing, pumps and packers. The lessee shall comply with the requirements in § 250.490 of this part as well as the appropriate requirements of this subpart.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998; 64 FR 9065, Feb. 24, 1999; 68 FR 8435, Feb. 20, 2003]

§ 250.605 Subsea workovers.

No subsea well-workover operation including routine operations shall be commenced until the lessee obtains written approval from the District Supervisor in accordance with § 250.613 of this part. That approval shall be based upon a case-by-case determination that the proposed equipment and procedures will maintain adequate control of the well and permit continued safe production operations.

[53 FR 10690, Apr. 1, 1988. Redesignated and amended at 63 FR 29479, 29485, May 29, 1998]

§ 250.606 Crew instructions.

Prior to engaging in well-workover operations, crew members shall be instructed in the safety requirements of the operations to be performed, possible hazards to be encountered, and general safety considerations to protect personnel, equipment, and the environment. Date and time of safety meetings shall be recorded and available at the facility for review by a Minerals Management Service representative.